
© 2015 Baltimore Aircoil International nv

VXC



Coil Casing Section

1. Drift eliminators
2. Spray branches
3. Spray branch grommets
4. Spray nozzles & nozzles grommets
5. Spray header
6. Coil(s)
7. Upper pump piping
8. Sleeve & clamps

Pan Fan Section


9. Lower pump piping
10. Spray pump
    - with volute
    - without volute
    - seal kit
11. Strainer
12. Make-up valve & arm
13. Float ball
14. Heater
15. Heater thermostat
16. Low level cut out switch
17. Centrifugal fan assembly (see detailed view)
18. Motor base with adjuster
19. Access door & gasket
20. Fan guard
21. Fan housing & fan snout
22. Fan inlet ring

Spray pump with volute





Spray pump without volute



Seal kit








Centrifugal fan assembly

- **A.** Centrifugal fan wheel
- **B.** Fan shaft
- **C.** Bearing drive end with locking collar
- **D.** Bearing non-drive end with locking collar
- **E.** Bearing support
- **F.** Impervix Fan motor
- **G.** Drive set
  - Motor sheave & bushing
  - Fan sheave & bushing
  - Belt set



Quantities may vary according to the unit type.

Spare parts for condenser

Client contact information

Name _____

Company _____

Telephone _____

Email _____

Unit model _____

Serial number _____

Your BAC contact

Name

Telephone

Email

This is not an official order form.