

# Safety switch

Dry and adiabatic cooling

## Options and accessories

### Safety switch



This switch

- facilitates inspection and maintenance
- prevents accidental risks during inspection or maintenance

Each individual motor is equipped with its own factory installed and wired safety switch. The switch safely isolates the motor and cuts the power. It is installed right next to each motor so that each motor can be clearly electrically isolated.

Contact your [local BAC representative](#) for guidance.